

7100 Technology Drive West Melbourne, FL 32904 1-800-422-6281

Service Bulletin

BKSB-1075 Issue Date: 5/2/2022



Issue: Resolves the following potential issues:

- Unterminated cloning when cloning from a DPH
- Will not power up due to "kernel" file loss or corruption
- "Lock-up" during standby or in scan modes

Resolves DTMF "Live Dial" being inoperative

Importance: High

Affected Models: BKR5000 Series

Recommended Action: Update unit with firmware version 5.8.57 (BK P/N BKR-FW-5.8.57). It is also recommended to update RES to 5.8.20 (BK P/N BKR0733-5.8.20) at the same time.

Radio Firmware Update

The "All-In-One" firmware application can be downloaded from BK Technologies, Inc. website at: https://bktechnologies.com/service-portal/products/BK BKR0733

Note: The release notes are included with the firmware download.

The release notes can be downloaded from BK Technologies, Inc. website at: Release Notes

Parts and Equipment Requirements:

- 1- BKR0710 Programming adaptor and USB Cable
- 1- Firmware Update from BKTechnologies.com

Procedure:

- 1. Verify the radio firmware revision installed in your BKR5000. Select "Versions" from the radio menu to see the radio firmware version.
- 2. Execute the "All-In-One" firmware application.
- 3. Connect the BKR0710 programming adaptor (portables) and USB cable.
- 4. Making sure the radio is off, push the PTT and switch the radio on.
- 5. The LED indicator on the radio should be flashing blue. Select the [Start] button on the application.

When firmware flashing is complete the radio will reboot and will be ready to use.

RES Software Download

The software editor P/N BKR0733-5.8.20 can be downloaded from the BK Technologies Website at: https://bktechnologies.com/service-portal/products

- 1. Select "KNG Digital Radios" or "BKR5000 Digital Radios" from the Product Support Software & Firmware Page
- 2. Select the respective Model
- 3. From the "Firmware & Software" Page, select the "Software" Tab at the top of the page



- 4. Select "Download" for the respective download
- 5. Enter the software Serial Number and select [Continue]
- 6. Follow the prompts