

## Tools

- Small Philips screw driver.
- Small pliers.
- KAA0630 KNG Dash mount installation kit.
- KAA0639C HCH Cab installation kit.
- Drill
- Loctite 243 or equivalent

or other vehicle components. Avoid splicing into old or existing lines.

The system must be used with a 12 volt DC, NEGATIVE GROUND electrical system.

the clip to the chassis using self tapping screws.

NOTE: If installing on KNG-M dashmount, install Interface Cable Bracket (Item 1) to the vehicle chassis. Options section in the KAA0670 User's Guide.

1411-31060-200

- 3. Mount the other end of the interface cable to the Interface Cable Bracket (Item 1) using the two Screwlocks (Item 2). Apply threadlocker Loctite 243 or equivalent prior to installation.
- 4. The KNG-M HCH can now be plugged into the connector mounted in the bracket.

7005-31061-000 INSTALLATION INSTRUCTIONS. KAA0639C www.bktechnologies.com

BRACKET, HANG-UP CLIP